

Mounting Instructions 08-12 BMW R1200GS



1. Place the bike on the center stand
2. Remove the stock bar caps, rest the bars on the tank or gauges. Remove the lower bar mounts.
3. Remove the plastic caps on each fork cap, Remove the nut on each fork using a 14mm socket.
4. Now with the forks hanging from the bike, you can remove the large nut on the bottom of the OEM steering stem stud.
5. Pull the triple clamp off and remove the 2 wire connections. You will need to take off the cover to get to the wires.
6. With the upper triple clamp removed, Press out the OEM steering stem stud from the triple clamp.
7. Press in the new GPR steering stem stud into the top triple clamp. (Photo 1)
8. Re-install the top triple clamp on the bike, plug in the two connections and snug down the steering stem nut. (Photo 2)
9. **ALIGN THE STEM STUD SO THE SQUARE DRIVE ON THE TOP IS PERFECTLY SQUARE TO THE STEERING.** Tighten the stem stud when aligned.
10. Slid the forks back into place and tighten the nuts on each fork tube.
11. Install the GPR V4 Fat Bar mount to the top triple clamp. (Photo 4)
12. Install the GPR Arm Bracket on the square drive on the stem.
13. install the GPR V4 Stabilizer into the bar mounts. Tighten the pinch bolt on the arm bracket (Photo 4)
14. Install the top GPR bar mount and set the bars to rider preference. (Photo 5 + 6)

Photo 1



Photo 2



Photo 3



Photo 4



Photo 5



Photo 6

